ADTH

nextgenTV

ADTH NEXTGEN TV Box

Quick Start Guide

nextgenTV Dolby Audio HDMI HIGH-DEFINITION MULTIMEDIA INTERFACE


HDR High Dynamic Range 4K UHD



Boot up screen




Pairing Remote Controls




Connect to Wi-Fi networks

Please connect to a network to complete the box setup for the first time.




Connect to Wi-Fi networks

Turn on the WiFi setting or connect to an Ethernet network.




Connect to Wi-Fi networks

Enter password for your Wi-Fi networks




Connect to Wi-Fi networks

Success




Connect to Wi-Fi networks

We strongly recommend connecting to the internet to complete the necessary updates, but if you really don't have internet access you can skip ahead and complete the updates later when internet access is available.




Auto Scan


Auto Scan
Scan and get channels
Please select your Country/Region and Standard
Country/Region
Standard
SCAN


Auto Scan

Choose Country and Scan




Auto Scan

Searching




Auto Scan

Searching Success




Set PIN code for Parental Control




Set PIN code for Parental Control

Choose viewing rating




Set PIN code for Parental Control

If you select "Restrict contents for 7+", any channel suitable for children aged 7 and over will require a PIN code to view.




Set PIN code for Parental Control

Enter PIN code




Set PIN code for Parental Control

Enter confirmation PIN code




Set PIN code for Parental Control

Setting Success




Set PIN code for Parental Control

You can also select “No restrictions” if you don’t need this function.




Automatic Update

Please Press OK to update to the latest version to complete the setup.




Automatic Update

You will be brought to the system upgrade page.




Automatic Update

The red dot marks items that can be updated. Press System App Update.




Automatic Update

The content of this update will be shown.




Automatic Update

Select Update Now and press OK.




Automatic Update


Will start to download and install the update.



Automatic Update




Automatic Update




Automatic Update

Installation Complete. Please press Quit.




Automatic Update

No update available. Please Press BACK key.




Home Screen

You will enter the home screen and the channel will start playing.




Electronic Program Guide (EPG)

EPG will start loading in the background.




Electronic Program Guide (EPG)

Press UP and DOWN keys on the remote to scroll down all channels.




Electronic Program Guide (EPG)

Press LEFT and RIGHT keys to scroll through the programs at different times.




Electronic Program Guide (EPG)

Press BACK key to return to the current time.




Preview Channel

When focusing on a program, the program guide will show up.



Preview Channel

Press OK, the program will be played in the preview window.



Preview Channel

Press OK again, you will go to full screen viewing.




Viewing in Full Screen




Full Screen - Channel List

Press UP key to show the channel list.




Full Screen - Channel List

Press LEFT and RIGHT keys to switch channels quickly.



Full Screen – Info Bar

Press DOWN key to pull up the info bar.



Multiple Audio Tracks

The rightmost icon is Audio Track setting.



Multiple Audio Tracks

Select the audio track you want to play.




Closed Captions

The second icon on the right is the Closed Captions setting.



Closed Captions

Choose the closed captions you want to show or not show.




Screen Ratio

The second icon on the left is the Screen Ratio setting.



Screen Ratio

Press OK, the aspect ration will be automatically adjusted.




Dialogue Enhancer

The leftmost icon is the Dialogue Enhancer setting.



Dialogue Enhancer

There are three levels of Dialogue Enhancer to choose from.



Broadcast App

When switching to a channel with a Broadcast App, a message to open the Broadcast App will appear on the screen.

Please connect to the Internet to get full advantage of Broadcast App.


Broadcast App

When BA message shows, press the right key on the remote control.




Broadcast App

The Broadcast App panel will show up on the screen.




Broadcast App

Use UP, DOWN, RIGHT, LEFT and OK keys to interact with Broadcast App contents. The panel style and contents may differ for each TV channel.



Broadcast App

You can see the weather, news, or play a video on demand in the Broadcast App.




Emergency Alert

When there is an alert, a warning message will appear on the screen.




Emergency Alert

Find more information about the alerts in the Alert page.




Parental Control

You can change PIN code or Viewing Rating in the Settings page.




Parental Control

Enter the PIN code you originally set (if you didn't set one, this step won't show).




Parental Control

Select the Viewing Rating you want to change.




Parental Control

Changed successfully




Parental Control

When switching to a restricted channel, enter the PIN code you set.



Parental Control

If the PIN code entered is wrong, you will not be able to view the channel.




Parental Control

Continue to watch TV after entering the correct PIN code.



Parental Control

You can change the PIN code at any time if necessary.




Manual Update

We will continue to improve and release updates to our software or firmware. Updating to the latest version will allow you to enjoy the latest features.


Manual Update

Before checking for updates, please connect to a network first.




Manual Update

Go to About page in the Setting, click Check to check for updates.




Manual Update

If there is an update available, click "Update" to enter the update page.




Manual Update

After pressing update, follow the same procedure as on page 21.



Manual Update

If there is no update available, it will show that it is the latest version.



Manual Update

If the Check failed, please make sure the network is well connected and try again.

